



BIOMASS COMBUSTION SYSTEMS, INC.

67 Millbrook Street, Suite 505


Worcester, MA 01606

Tel: 508-798-5970/Fax: 508-798-5971

www.biomasscombustion.com

Air Make up

When exhaust fans are on, a vent to the outside lets cold air into the furnace room. This air is warmed by the radiant heat off the furnace before being blown through the furnace and into the plant for air make up



At night, when exhaust fans are off, the vent to the outside is shut and a return vent from the plant is opened so warm air from the plant can be circulated through the furnace room